

OAM

OAM and product documentation Rampline AS

Innovation and quality since 2008

Rampline AS is a Norwegian company that develops and delivers play and activity equipment for the public environment. Rampline products provides physical development through play and especially stimulates and develop balance and motor skills.

Production and preparation of the products are done at our facility in Talgje, Norway. All our products are in accordance with EN 1176-1:2017.

Mounting instructions are included with all our products.

The importance of maintenance

Damage or malfunction to the play equipment may pose a hazard to the user. Additionally, it will degrade the user experience and the products may be damaged. Therefore, errors should always be corrected. When removing products, always secure the open mounting holes.

Read more about maintenance on www.rampline.no

About the anchoring system

Our play equipment is mounted to concrete foundations with expansion bolts. No movement should be possible at the attachment point. Improper installation, incorrect concrete grade, vandalism or vehicles that collide with the devices can lead to slack at the attachment point.

Spare parts

If vandalism or need for extended maintenance occurs, Rampline AS offers all spare parts throughout the product life. The products are designed with a practical access for replacement of individual parts.

Warranty

See our product warranty description www.rampline.no/product-warranty



OAM and product documentation

PLAYPRO™ trampoline edge protection

PlayPro™ is a edge protection ring made of natural rubber. It act as shock absorption and has a non slip texture.

The product is developed by Rampline AS, designed for Eurotramp's trampolines Playground Loop 1.0 and Loop 1.5.

The product's purpose is to protect the user from the steel edge of the trampoline structure, to protect the trampoline's spring attachment, as well as to visually integrate the trampoline with the surrounding area (wet pour rubber ground cover).

PlayPro™ is glued to the trampoline's steel suspension box.

Surface care

Clean with soap and water or rinse gently with high pressure washer.

The rubber surface may be visually affected by sunlight and wear. It can be wax treated to restore its original shine and color. Contact Rampline for guidance.

If minor damages to the rubber should occur this can be repaired in place by gluing. Contact Rampline for guidance.

Attachment

PlayPro™ is glued to the trampoline suspension box with SuperFix+ glue. If parts of th edge protection has come loose please refer to the PlayPro™ mounting instructions or contact Rampline.